



bags




Tighten cap. before inflating.




Press nozzle in air valve.
Caution. Watch Pressure



Secure air valve with plug



Sizes: bag width 60 80 100 cm
Max void width 30 35 40 cm



To deflate, turn left 180 degrees.



Store with open valve



Do not step on the
Transystem Plus